

Revolution counter	TU00-0752-6307102	02/11 	1-11 1
--------------------	-------------------	-----------	--------

Safety information



- The product was developed, manufactured and inspected according to the basic safety requirements of EC Guidelines and state-of-the-art technology.
- The unit is designed for use in grounded vehicles and machines as well as in nautical sports, including non-classified commercial shipping.
- Use our product only as intended. Use of the product for reasons other than its intended use may lead to personal injury, property damage or environmental damage. Before installation, check the vehicle documentation for vehicle type and any possible special features!
- Use the assembly plan to learn the location of the fuel/hydraulic/ compressed air and electrical lines!
- Note possible modification to the vehicle, which must be considered during installation!
- To prevent personal injury, property damage or environmental damage, basic knowledge of motor vehicle/shipbuilding electronics and mechanics is required.
- Make sure that the engine cannot start unintentionally during installation!
- Modifications or manipulations to the VDO product can affect safety. Consequently, you may not modify or manipulate the product!
- When removing/installing seats, covers, etc., ensure that lines are not damaged and plug-in connections are not loosened!
- Note all data from other installed units with volatile electronic

Safety during installation:

- During installation, ensure that the product's components do not affect or limit vehicle functions. Avoid damaging these components!
- Only install undamaged parts in a vehicle!
- During installation, ensure that the product does not impair the field of vision and that it cannot impact the driver's or passenger's head!
- A specialized technician should install the product. If you install the product yourself, wear appropriate work clothing. Do not wear loose clothing, as it may get caught in moving parts. Protect long hair with a hair net.
- When working on the on-board electronics, do not wear metallic or conductive jewelry such as necklaces, bracelets, rings, etc.
- If work on a running engine is required, exercise extreme caution. Wear only appropriate work clothing as you are at risk of personal injury, resulting from being crushed or burned.
- Before taking any action, disconnect the negative terminal on the battery, otherwise you risk a short circuit. If the vehicle is supplied by auxiliary batteries, you must also disconnect the negative terminals on these batteries! Short circuits can cause fires, battery explosions and damages to other electronic systems. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.
- If working on gasoline boat motors, let the motor compartment fan run before beginning work.
- Pay attention to how lines and cable harnesses are laid so that you do not drill or saw through them!
- Do not choose to install the product in the mechanical and electrical airbag area!
- Do not drill holes or ports in load-bearing or stabilizing stays or tie bars!
- When working underneath the vehicle, secure it according to the specifications from the vehicle manufacturer.
- Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm.
- Drill small ports; enlarge and complete them, if necessary using taper milling tools, saber saw, keyhole saw or file. Debur edges. Follow the safety instructions of the tool manufacturer.
- Use only insulated tools, if work is necessary on live parts.
- Use only the multimeter or diode test lamps provided, to measure voltages and currents in the vehicle/machine or ship. Use of conventional test lamps can cause damage to control units or other electronic systems.

No Smoking! No open fire or lights!





- The electrical indicator outputs and cables connected to them must be protected from direct contact and damage. The cables in use must have sufficient insulation and electric strength and the contact points must be safe from touch.
- Use appropriate measures to also protect the electrically conductive parts on the connected consumer from direct contact. Laying metallic, uninsulated cables and contacts is prohibited.




Safety after installation:

- Connect the ground cable tightly to the negative terminal of the battery.
- Reenter/reprogram the volatile electronic memory values.
- Check all functions.
- Use only clean water to clean the components. Note the Ingress Protection (IP) ratings (IEC 60529).


Electrical connection:

- Note cable cross-sectional area!
- Reducing the cable cross-sectional area leads to higher current density, which can cause the cable cross-sectional area in question to heat up!
- When installing electrical cable, use the provided cable ducts and harnesses, however, do not run cables parallel to ignition cables or to cables that lead to large electricity consumers.
- Fasten cables with cable ties or adhesive tape. Do not run cables over moving parts. Do not attach cables to the steering column!
- Ensure that cables are not subject to tensile, compressive or shearing forces.
- If cables are run through drill holes, protect them using rubber sleeves or the like.
- Use only one cable stripper to strip the cable. Adjust the stripper so that stranded wires are not damaged or separated.
- Only use a soft soldering process or commercially available crimp connector to solder new cable connections!
- Only make crimp connections with cable crimping pliers. Follow the safety instructions of the tool manufacturer.
- Insulate exposed stranded wires to prevent short circuits.
- Caution: Risk of short circuit if junctions are faulty or cables are damaged.
- Short circuits in the vehicle network can cause fires, battery explosions and damages to other electronic systems. Consequently, all power supply cable connections must be provided with weldable connectors and be sufficiently insulated.
- Ensure ground connections are sound.
- Faulty connections can cause short circuits. Only connect cables according to the electrical wiring diagram.
- If operating the instrument on power supply units, note that the power supply unit must be stabilized and it must comply with the following standard: DIN EN 61000, Parts 6-1 to 6-4.

Revolution counter		TU00-0752-6307102	02/11 GB	1-11	2																		
Procedures for installing VDO Viewline instruments																							
1 		Before beginning, turn off the ignition and remove the ignition key. If necessary, remove the main circuit switch.																					
2 		 Before taking any action, disconnect the negative terminal on the battery, otherwise you risk a short circuit. If the vehicle is supplied by auxiliary batteries, you must also disconnect the negative terminals on these batteries! Short circuits can cause fires, battery explosions and damages to other electronic systems. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.																					
3 		If installing the instrument near a magnetic compass, note the magnetic safe distance to the compass.																					
4 		The following rings may be installed as alternatives to the supplied front ring: <table><tr><td>Front ring, flat; black</td><td>A2C53210745</td></tr><tr><td>Front ring, flat; white</td><td>A2C53210746</td></tr><tr><td>Front ring, flat; chrome</td><td>A2C53210747</td></tr><tr><td>Front ring, triangular; black</td><td>A2C53210763</td></tr><tr><td>Front ring, triangular; white</td><td>A2C53210764</td></tr><tr><td>Front ring, triangular; chrome</td><td>A2C53210765</td></tr><tr><td>Front ring, round; black</td><td>A2C53210749</td></tr><tr><td>Front ring, round; white</td><td>A2C53210760</td></tr><tr><td>Front ring, round; chrome</td><td>A2C53210761</td></tr></table>				Front ring, flat; black	A2C53210745	Front ring, flat; white	A2C53210746	Front ring, flat; chrome	A2C53210747	Front ring, triangular; black	A2C53210763	Front ring, triangular; white	A2C53210764	Front ring, triangular; chrome	A2C53210765	Front ring, round; black	A2C53210749	Front ring, round; white	A2C53210760	Front ring, round; chrome	A2C53210761
Front ring, flat; black	A2C53210745																						
Front ring, flat; white	A2C53210746																						
Front ring, flat; chrome	A2C53210747																						
Front ring, triangular; black	A2C53210763																						
Front ring, triangular; white	A2C53210764																						
Front ring, triangular; chrome	A2C53210765																						
Front ring, round; black	A2C53210749																						
Front ring, round; white	A2C53210760																						
Front ring, round; chrome	A2C53210761																						
5 		Place the new front ring on the instrument, rotate it until the ring's lip locks into the slots in the housing and press the front ring until it is flush with the instrument glass.																					
6 		 - Do not drill holes or ports in load-bearing or stabilizing stays or tie bars! - Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm. - Drill small ports; enlarge and complete them, if necessary using taper milling tools, saber saw, keyhole saw or file. Debur edges. Follow the safety instructions of the tool manufacturer. Conventional assembly. (Instrument is put into the drill hole from the front). The panel width may be within a range of 0.5 to 20 mm. The drill hole must have a diameter of 111 mm.																					

Revolution counter	TU00-0752-6307102	02/11 	1-11 3
7 	If the instrument is mounted flush (i.e., from the back so that the instrument glass and the panel form one plane), the front ring must be removed. Press the instrument glass with both thumbs, while at the same time pressing the front ring forward from the instrument with both index fingers. Note the use of a tool in the adjacent figure.		
8  • Do not drill holes or ports in load-bearing or stabilizing stays or tie bars! • Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm. • Drill small ports; enlarge and complete them, if necessary using taper milling tools, saber saw, keyhole saw or file. Debur edges. Follow the safety instructions of the tool manufacturer.	Flush Montage. The recommended panel thickness is 1.5 to 3 mm. The drill hole must have a diameter of 105.4 mm. Ensure that the installation location is level and has no sharp edges.		
9 	Place the flush mount seal A2C53215641 on the instrument glass. Put the instrument into the drill hole from the back. Adjust the instrument so that the gauge is level and fasten it to the stud bolts on the rear side of the panel, using the flush mount fixing bracket A2C59510864.		

Revolution counter	TU00-0752-6307102	02/11	1-11	4
		GB		



Now insert the plug into the gauge.
Note the inverse polarity protection nose in the process.

Depending on the configuration, insert the cable into the 8-pin and 14-pin contact housing according to the following pin assignment. The contacts must audibly lock into place.

8-pin contact housing

- Pin 1 - Term. 30 - battery 12/24 V
- Pin 2 - Term. 31 - ground
- Pin 3 - signal ground
- Pin 4 - Term. 15 - ignition plus
- Pin 5 - sensor signal
- Pin 6 - Term. 58 - lighting
- Pin 7 - programming port Tx
- Pin 8 - programming port Rx


14-pin contact housing

- Pin 1 - unassigned
- Pin 2 - unassigned
- Pin 3 - unassigned
- Pin 4 - unassigned
- Pin 5 - unassigned
- Pin 6 - unassigned
- Pin 7 - unassigned
- Pin 8 - unassigned
- Pin 9 - unassigned
- Pin 10 - unassigned
- Pin 11 - Configuration key
- Pin 12 - Mode key
- Pin 13 - Alarm output (max 100 mA*)
- Pin 14 - unassigned

* optional, please contact your VDO partner for more information.


Revolution counter	TU00-0752-6307102	02/11 GB	1-11 5
--------------------	-------------------	-------------	--------

11



Connector set, 8-pin -
A2C59510850

Connector set, 14-pin -
A2C59510851



Electrical connection:

- Electrical connection:
- Note cable cross-sectional area!
- Reducing the cable cross-sectional area leads to higher current density, which can cause the cable cross-sectional area in question to heat up!
- When installing electrical cable, use the provided cable ducts and harnesses, however, do not run cables parallel to ignition cables or to cables that lead to large electricity consumers.
- Fasten cables with cable ties or adhesive tape. Do not run cables over moving parts. Do not attach cables to the steering column!
- Ensure that cables are not subject to tensile, compressive or shearing forces.
- If cables are run through drill holes, protect them using rubber sleeves or the like.
- Use only one cable stripper to strip the cable. Adjust the stripper so that stranded wires are not damaged or separated.
- Only use a soft soldering process or commercially available crimp connector to solder new cable connections!
- Only make crimp connections with cable crimping pliers. Follow the safety instructions of the tool manufacturer.
- Insulate exposed stranded wires to prevent short circuits.
- Caution: Risk of short circuit if junctions are faulty or cables are damaged.
- Short circuits in the vehicle network can cause fires, battery explosions and damages to other electronic systems. Consequently, all power supply cable connections must be provided with weldable connectors and sufficiently insulated.
- Ensure ground connections are sound.
- Faulty connections can cause short circuits. Only connect cables according to the electrical wiring diagram.
- If operating the instrument on power supply units, note that the power supply unit must be stabilized and it must comply with the following standard: DIN EN 61000, Parts 6-1 to 6-4.

Use the following connector to connect the instrument:

Connector set, 8-pin - A2C59510850

Connector set, 14-pin - A2C59510851

The connector set is designed for a cable cross-section of 0.25 - 0.5 mm².

For other cross-sections, please use contacts made by Tyco.

Single contacts: Tyco No. 1355718-1 for 0.14 - 0.22 mm²

Tyco No. 963729-1 for 0.5 - 0.75 mm²

Strip: Tyco No. 1355717-1 for 0.14 - 0.22 mm²

Tyco No. 963715-1 for 0.5 - 0.75 mm²

Create a crimp connection using the contacts and the corresponding cables. Follow the instructions of the hand pliers manufacturer. Use the following for this:

Hand pliers Tyco No. 539635-1

And the tool Tyco No. 539682-2 for these hand pliers.

Pay special attention to whether the crimp barrel clutches all individual wires in the cable, otherwise you risk a short circuit!

12

Bezeichnungen innerhalb des Anschlussplans:

30 - terminal 30 - steady-state plus 12 V

15 - terminal 15 - connected (ignition) plus

58 - terminal 58 - lighting

31 - terminal 31 - ground

F1 - fuse 5A quick-response

C1 - 8-pin MQS connector

C2 - 14-pin MQS connector


Config - Configuration key

Mode - Mode key


W1 - Alarm output (max. 100 mA)

You must comply with the wiring diagram.

8-pin connection



14-pin connection



Revolution counter	TU00-0752-6307102	02/11 GB	1-11 6
13	Align the instrument and hand-tighten the fastening nut. Ensure that the nut is not tightened with a torque greater than 400 Ncm. * Make sure the seal lays flat between the panel and the front ring.		
14	If you would like to omit the fastening nut, you may use the part set A2C59510854 as an alternative. This is recommended if the installation location is subject to vibratory loads. Screw the stud bolts into the provided drill holes in the enclosure. Max. stud bolt torque is 1.5 Nm		
15	Place the bracket on the stud bolt and hand-tighten the knurled nut. * Make sure the seal lays flat between the panel and the front ring (see Fig. 13).		
16	Reconnect the battery after inspecting the connection. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.		
17	If necessary, replace the main circuit switch. Turn on the ignition and conduct a functional test. Reprogram other instruments that may have lost their saved settings.		

Revolution counter	TU00-0752-6307102	02/11	1-11	7
		GB		


18 Operation

Basics:

Press the key briefly (< 2sec.) to change the currently displayed value.
Press the key longer (> 2sec.) to change to the next value.
The display returns to normal operating mode if a key is not pressed for 30 seconds.
Any settings you have made are not saved.





Startup

1. Setting the impulse number

	1. Activate T. 30 (8-pin - Pin1) 2. Deactivate T. 15 (8-pin - Pin4) 3. Press and hold Config key (14-pin - Pin 11)
	Activate T. 15 Release Config key
	
	Press and hold Config key
	Set impulse number is displayed; the first digit flashes
	Press Config key briefly
	The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"
	Press and hold Config key
	The next lower digit flashes
	Press Config key briefly
	The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"
	Continue until the complete impulse number is set
	Press and hold Config key
	Deactivate T. 15. This saves the impulse number in the display.

Revolution counter	TU00-0752-6307102	02/11	1-11	8
		GB		

2. Setting the unit and alarm threshold


	1. Activate T. 30 (8-pin - Pin1) 2. Deactivate T. 15 (8-pin - Pin4) 3. Press and hold Mode key (14-pin - Pin 12)
	Activate T. 15 Release Mode key
	
	Press and hold Mode key
	By briefly pressing the Mode key, you can switch between 24h and 12h (AM/PM) clock format.
	Press and hold Mode key
	
	Press Mode key briefly
	
	Press and hold Mode key
	Set alarm threshold is displayed; the first digit flashes.
	Press Mode key briefly
	The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"
	Press and hold Mode key
	The next lower digit flashes.
	Press Mode key briefly
	The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"
	Continue until the complete alarm threshold is set.
	Press and hold Mode key
	Deactivate T. 15. This saves the unit and the alarm threshold in the display.

Revolution counter		TU00-0752-6307102	02/11	1-11	9
					
In operation					
1. Display indicator selection					
		1. Activate T. 30 (8-pin - Pin1) 2. Activate T. 15 (8-pin - Pin4)			
Total operating hours					
		Press Mode key briefly			
Trip hours					
		Press Mode key briefly			
Time					
		Press Mode key briefly			
On-board voltage					
2. Resetting the day counter					
		1. Activate T. 30 (8-pin - Pin1) 2. Activate T. 15 (8-pin - Pin4)			
		Press the Mode key repeatedly until the trip hours are displayed			
					
		Press and hold Mode key			
					
		Trip is now deleted.			

Revolution counter		TU00-0752-6307102		02/11	1-11	10
						
3. Setting the clock						
		1. Activate T. 30 (8-pin - Pin1) 2. Activate T. 15 (8-pin - Pin4)				
		Press the Mode key repeatedly until the time is displayed				
		Press and hold Mode key				
		Set time is displayed; the first digit flashes				
		Press Mode key briefly				
		The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"				
		Press and hold Mode key				
		The next lower digit flashes.				
		Press Mode key briefly				
		The flashing digit increases by 1. If the flashing digit is "9", the display returns to "0"				
		Continue until the correct time is set				
		Press and hold Mode key				
		Clock is set. Important: If T. 30 (8-pin - Pin1) is deactivated, the clock no longer runs.				
4. Setting the brightness						
		1. Activate T. 30 (8-pin - Pin1) 2. Activate T. 15 (8-pin - Pin4)				
		Press the Mode key repeatedly until the on-board voltage is displayed				
						
		Press and hold Mode key				
		Press the Mode key repeatedly until the desired brightness is reached The brightness can be set between 0 (OFF) to 10 (max).				
						
		Press and hold Mode key				
		The desired brightness is now permanently set.				

Revolution counter	TU00-0752-6307102	02/11	1-11	11
		GB		

19



To remove the connector, press the latch (1) and pull the connector out (2).

20

Important: Clean the instrument glass and front frame with water only. Do not use chemical agents.

21

Accessories / Spare parts

Bush contacts 0.25 – 0.5 mm²	A2C59510846	Fastening nut	A2C53238881
Bush housing, 8-pin	A2C59510847	Front ring, flat; black	A2C53210745
Bush housing, 14-pin	A2C59510848	Front ring, flat; white	A2C53210746
Hand pliers	Tyco No. 539635-1	Front ring, flat; chrome	A2C53210747
Tool for hand pliers	Tyco No. 539682-2.	Front ring, triangular; black	A2C53210763
Single contacts 0.14 – 0.22 mm²	Tyco No. 1355718-1	Front ring, triangular; white	A2C53210764
Single contacts 0.5 – 0.75 mm²	Tyco No. 963729-1	Front ring, triangular; chrome	A2C53210765
Strip 0.14 – 0.22 mm²	Tyco No. 1355717-1	Front ring, round; black	A2C53210749
Strip 0.25 – 0.5 mm²	Tyco No. 928999-1	Front ring, round; white	A2C53210760
Strip 0.5 – 0.75 mm²	Tyco No. 963715-1	Front ring, round; chrome	A2C53210761
Bracket assembly mounting set	A2C59510854	Protective connector cap, 8-pin	A2C53324664
Flush mount fixing bracket	A2C59510864	Protective connector cap, 14-pin	A2C53324671
Flush mount seal	A2C53215642		